

# **MICROWAVE SENSOR**

MWS-ST-11-24C[TRANSMITTER]
MWS-SR-11-24C[RECEIVER]

PAT. PEND.



# MICROWAVE SENSOR MWS-ST-11/SR-11-24C

# Due to the sensor's high penetrability, surface contaminants and harsh environments do not affect its operation.

# **General**

The MWS-ST/SR-24C type microwave sensor is a level switch consisting of a transmitter (MWS-ST) and a receiver (MWS-SR) installed face-to-face. The transmitter emits a continuous, low power microwave beam towards the receiver and an output relay is released when the beam is obstructed.

The sensor has wide application across all areas of industry where highly reliable, non-contact level detection is required. The sensor is generally used for process control by monitoring presence/absence of product, flow/no flow conditions and point level detection in bins and silos. The sensor may also be used as a proximity switch for detection of vehicles such as dump trucks and rail cars.

# **Features**

# High penetration

Easily penetrates process buildup on antenna, firebrick, refractory etc., thanks to the increased operating range.

# Unaffected by adverse environments

The sensor is unaffected by surface contaminants, flames, steam, vapor or airborne particles.

# Simple beam alignment

Easy initial beam alignment at installation, due to the wide beam angle.

#### Selectable detection mode


Either broken beam (BLOCK) or unbroken beam (UNBLOCK) detection method may be selected.

# Small sensing head (Ø27mm/1in)

Approximately 100m/325ft range with Ø27mm/1in antenna.

# Enclosure rating IP65/NEMA4 equivalent

# Wiring



# Selection of detection mode and relay configuration.

<b>,g</b>						
Detection mode		Beam broken BLOCK		Beam unbroken UNBLOCK		
Terminal number		4 & 5	5 & 6	4 & 5	5 & 6	
Unpowered state		Closed	Open	Closed	Open	
Powered state	Non-detecting state	Open	Closed	Open	Closed	
	Detecting state	Closed	Open	Closed	Open	

# **Penetrability of microwaves**

Harsh environments may result in a buildup of contaminants on the sensing head; however, the sensor is easily able to penetrate such buildup thanks to the high penetrability of microwaves.


When microwaves transmitted through air encounter an object, some will be reflected, some absorbed and the rest will pass through the object. The amount of microwaves passing through the object depends on its composition.

Generally speaking, microwaves cannot penetrate metals

Generally speaking, microwaves cannot penetrate metals and are reflected; water absorbs the most microwaves.

# State-of-the-art Heterodyne Detection Method

The MWS-ST/SR level switch is the first of its kind to utilize the heterodyne detection method rather than the, now obsolete, diode detection method.



Received power level


The heterodyne detection method gives detection output that is proportional to the received power level, whereas the diode detection method gives detection output that is proportional to the square of the received power level.

Therefore the heterodyne method allows detection with a minimum received power that is lower than that of the minimum level required by the diode detection method. This greatly increases the operating range/penetrability without any increase in the power of the transmitted microwave radiation.




# Function of receiver switches and rheostats

# **Transmitter**



	Part Name	Description
1	Power indicator	Green when power is on
2	Block button	Blocks transmission
3	Terminals	Power supply(1~3)

# Receiver



	Part Name	Description
1	Mode selection switch	BLOCK: Outputs on broken beam UNBLOCK: Outputs on unbroken beam
2	Delay time rheostat	0.1 - 10sec. delay period after state changes
3	Output indicator	ON (red) : Illuminates on output
4	Output indicator	OFF (green) : Illuminates on no output
(5)	Sensitivity switch	H:High sensitivity L:Low sensitivity
6	Sensitivity rheostat	For sensitivity adjustment
7	Terminals	Power supply(1~3) and relay contacts(4~6)

# **Adjustment**

After installation is complete, adjust the following with the sensor in the UNBLOCK state.

#### Transmitter

• Upon turning on the power supply, the POWER light ①(Green) will come on.

#### Receiver

- Upon turning on the power supply, either the red BLOCK light ③ or the green UNBLOCK light ④ will come on.
- Turn mode selection switch ① to BLOCK, turn the sensitivity switch ⑤ to L and turn the delay time rheostat ② fully counter-clockwise (minimum).
- Set the sensitivity rheostat 6 to minimum.
- The red output indicator ON ③ will come on.
- Slowly turn the sensitivity rheostat ⑥ clockwise until the green output indicator OFF ④ comes on.

This is to determine the actuation point. If this sensitivity setting is very high (more than 7 on the rheostat) switch the sensitivity switch ⑤ to H and repeat the above procedure.

- For applications involving mainly paper and/or where there is little accumulation on the sensing head, increment the rheostat
   by 1 or 2 levels only.
- On the other hand, where the application involves material with a moderately high water content, i.e. wet garbage etc, then the rheostat ⑥ should be incremented by 3-4 steps.
- However, if the object to be detected absorbs microwaves well, (i.e. coal), then the rheostat ® can be incremented by more than 5 steps.
- For an application where material is introduced from above, a suitable "delay" time must be provided to avoid instantaneous detection of the falling material.
- $\bullet$  To use UNBLOCK output mode, switch the mode selection switch 1 to UNBLOCK.



# **Specifications**

	Transmitter	Receiver			
Туре	MWS-ST-11-24C	MWS-SR-11-24C			
Power supply	DC24V ±10%				
Power consumption	0.5W	1W			
*Operating distance	40mor less				
Frequency and transmission power	Approx. 24GHz, less than 100mW E.I.R.P.				
Compliance	Complies with all EEC directives for use in heavy industrial environment				
Radiation angle	Approx. ±20° (angle in half of receiving value)				
Output contact		1C (SPDT) relay contact DC30V, 2A			
Response time		10msec.			
On delay		0.1 ~ 10sec.			
Delay time from power on to function	Approx. 50msec.	Approx. 5sec.			
Operating ambient temperature	-10°C ~ +55°C				
Non-function ambient temperature	-20°C ~ +70°C				
Continuous maximum pressure	0.5MPa				
Enclosure rating	IP65 equivalent				
Enclosure construction	Diecast aluminum				
Color	Metallic silver grey				
Weight	1kg	1kg			


<sup>\*</sup> The operating distance may vary from sensor to sensor and according to installation.

# Installation

Install the transmitter and receiver face to face as shown below.

Both unit's cable entry should face in the same direction, or be  $180^{\circ}$  opposite each other.


Cable entry in the same direction.




Cable entry 180° opposite each other.




If the units are installed with cable entries at  $90^{\circ}$  to each other they will not function.



If two transmitter-receiver sets are installed in close proximity, one transmitter-receiver set should be mounted at a  $90^{\circ}$  angle to the other so that the waves of one unit will not interfere with the other's.



# **Dimensions**



This specification may be changed without notification.



# WIRE AUTOMATIC DEVICE CO.,LTD.

**HEAD OFFICE** 

1-12-9, Meishin-cho, Amagasaki-shi, Hyogo-ken 661-0021, Japan

TEL.81-6-6482-3838 FAX. 81-6-6481-6321

TOKYO BRANCH

202 Shibuya-homes,2-1,Udagawa-cho,Shibuya-ku,Tokyo

150-0042, Japan

TEL.81-3-3770-5519 FAX.81-3-3770-5520

URL: http://www.wadeco.co.jp